

Instructions


Copy key

Type EKA 182A

084R9968

EKC → EKA 182A


1) Power off



3) Power on


4) o65 = No. 1.....25
Enter

5) Power off



EKA 182A → EKC

1) Power off




3) Power on

4) r12 = 0 | Not necessary
Enter | for controllers
as on 2008

5) o66 = No. +1.....+25
Enter

6) Power off



8) Power on

9) (r12 = 1 = start regulation)

084R9968

© Danfoss A/S, FC-SPMC